HOLIDAY LIGHT HANGING SAFETY TIPS

BRING THE HOLIDAY CHEER—SAFELY! DECORATING WITH CHRISTMAS LIGHTS IS FUN, BUT A FEW SIMPLE PRECAUTIONS CAN PREVENT THE MOST COMMON INJURIES OF THE SEASON.

LADDER SAFETY

- Choose the right ladder for the job—**don't stretch or lean.**
- Place ladders on **level, stable ground** and maintain **three points of contact.**
- Keep the area clear of doors, traffic, or anything that might bump the ladder.
- Never climb with your hands full—use a tool belt or hoist items up safely.

ELECTRICAL SAFETY

- Use **outdoor-rated lights**, cords, and timers.
- Inspect light strings for **cracks, frayed wires, or loose bulbs.**
- Avoid overloading outlets or connecting more strands than the manufacturer allows.
- Keep cords away from water, pinch points, and sharp edges.
- Always **unplug lights before adjusting or installing.**

GENERAL TIPS

- Work with a **buddy**—spotters make everything safer.
- Avoid decorating in wet, icy, or windy conditions.
- Take your time—**rushing leads to slips and shocks.**

Make your holidays merry, bright, and injury-free! If you see something unsafe, speak up and fix it before it becomes a problem.